

# 3-Way ball valve Type23 Pneumatic Actuated Type TA 15~100mm

## User's Manual



Thank you for choosing our product.

This User's manual contains important information for safe use of our product, so please be sure to read it before handling the product. After reading this manual, please be sure to keep it in a place where the user can see it at any time.

## ASAHI YUKIZAI CORPORATION

**-SAFETY PRECAUTIONS-**

This User's manual is written on the assumption that the person who handles our products has a basic knowledge of our products, electrical equipment, machinery, control, etc., and it contains technical terms depending on the handling contents.

Please read this manual carefully and fully understand the contents and observe the safety precautions for proper use.

In this manual, the warning, caution, prohibition, and enforcement are categorized together with the symbol to inform the situation and scale of human injury or property damage.

Failure to observe this precaution may result in unexpected failure or damage. Be sure to observe this precaution.

**<WARNING/CAUTION indications>**

|  |   |
|--|---|
|  <b>Warning</b> | Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.                   |
|  <b>Caution</b> | Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or property damage. |

**<Prohibited/Forced display>**

|  |  |
|--|--|
|  <b>Prohibition</b> | In the handling of the product, it is prohibited to do it in "Do not do it".               |
|  <b>Forcing</b>     | In the handling of the product, it is forced by "contents to be carried out without fail". |

**Table of contents**

**1. Our product warranty coverage..... 4**

    Applicable to ..... 4

    Warranty Period..... 4

    Guaranteed range..... 4

    Disclaimer..... 4

**2. Safety Instructions..... 5**

    Unpacking, Transportation and Storage..... 5

    Product Handling..... 6

**3. Name of each part..... 8**

**4. Product Specifications ..... 9**

    Model number table..... 9

    Relationship between maximum allowable pressure and temperature ..... 10

    Actuator..... 11

**5. Optional specifications..... 12**

**6. Piping method..... 15**

    Flanged end..... 15

    Threaded end..... 17

    Socket end (adhesive)..... 19

    Socket end, Spigot end (Fusing)..... 21

    Support of the product ..... 23

**7. Air piping method ..... 25**

**8. Wiring method..... 29**

    Limit switch..... 29

    Solenoid valve ..... 31

**9. Commissioning method ..... 33**

**10. How to disassemble/assemble parts for replacement..... 42**

**11. Inspection item..... 44**

    Daily inspection ..... 45

    Periodic inspection..... 47

**12. Cause of malfunction and remedy ..... 49**

**13. Disposal method of residual materials and waste materials..... 56**

**Inquiries..... 57**

## 1. Our product warranty coverage

Unless otherwise stated in the Contract or Specifications, etc., the warranty for the piping material products (hereinafter referred to as "applicable products") such as valves manufactured or sold by us is as follows.

### Applicable to

This warranty applies only when the product is used in Japan. If you intend to use the product overseas, please contact us.

### Warranty Period

The warranty period is one year after delivery.

### Guaranteed range

In the event of failure or malfunction due to our responsibility during the above warranty period, we will replace or repair the product with a substitute free of charge.

Provided, however, that even within the warranty period, the warranty shall not apply to any of the following cases (charged service).

- ▶ When the storage, operating conditions, precautions, etc. described in the specifications, User's manual, etc. are not adhered to in the construction, installation, handling, maintenance, etc.
- ▶ Defects, such as the design of the customer's equipment or software, caused by other than the target product.
- ▶ The fault is due to modification or secondary processing of the product by something other than us.
- ▶ In the case of a failure which can be deemed to have been avoided if the periodic inspection described in the User's manual, etc. or the maintenance or replacement of consumable parts has been performed normally.
- ▶ The component is used for purposes other than the product's intended use.
- ▶ Failure or malfunction due to causes that could not be foreseen by our level of science and technology at the time of shipment.
- ▶ The fault is due to an external factor that is not our responsibility, such as natural disaster or disaster.

### Disclaimer

- ▶ The warranty will not cover secondary damage (damage to equipment, loss of opportunity, loss of profit, etc.) or any other damage caused by the failure of our product.
- ▶ Although we strive to improve the quality and reliability of our products, we do not guarantee their integrity. Especially when using this product for equipment that may infringe human life, body or property, take appropriate safety design measures, etc., with full consideration of problems that may normally occur. We assume no responsibility for such use if we have not obtained our consent in advance in writing of specifications, etc.
- ▶ Please observe the product specifications and precautions when using our products. We shall not assume any responsibility for any damage to the customer caused by the customer's negligence. However, this does not apply to damage caused by a defect in our product.

**2. Safety Instructions**

**Unpacking, Transportation and Storage**

|  |   |
|--|---|
|  <b>Warning</b>     |   |
|  <b>Prohibition</b> | <p><b>Serious injury can result.</b></p> <ul style="list-style-type: none"> <li>▶ When hanging or slinging a valve, pay sufficient attention to safety, and do not enter under the load.</li> </ul> |

|  |  |
|--|--|
|  <b>Caution</b>     |  |
|  <b>Prohibition</b> | <p><b>The valve can be damaged, or leak.</b></p> <ul style="list-style-type: none"> <li>▶ Do not subject the product to impact by throwing, dropping or hitting.</li> <li>▶ Do not scratch or pierce the product with a sharp object such as a knife or hand hook.</li> <li>▶ Do not pile up cardboard boxes forcefully to prevent the load from collapsing.</li> <li>▶ Avoid contact with coal tar, creosote (a wood preservative), white pesticides, insecticides, paints, etc.</li> </ul>               |
|  <b>Forcing</b>    | <p><b>The valve can be damaged, or leak.</b></p> <ul style="list-style-type: none"> <li>▶ Keep in cardboard until just before piping, and store indoors (at room temperature) away from direct sunlight. Also, avoid storing the product in places of high temperature. (The strength of cardboard packaging decreases when it gets wet. Be very careful when storing and handling it.)</li> <li>▶ After unpacking, make sure that the product is correct and that it meets the specifications.</li> </ul> |

**Product Handling**

|  <b>Warning</b>     |  |
|--|--|
|  <b>Prohibition</b> | <p><b>Serious injury can result.</b></p> <ul style="list-style-type: none"> <li>▶ Do not disassemble the actuator.</li> <li>▶ Do not touch moving parts during operation with hands, feet or tools.</li> </ul>   |
|  <b>Forcing</b>     | <p><b>There is a danger of injury.</b></p> <ul style="list-style-type: none"> <li>▶ If positive pressure gas is used for our resin piping material, a dangerous condition may occur due to the repulsive force peculiar to compressible fluids even if the pressure is the same as the water pressure. Therefore, be sure to take safety measures for the surrounding area, such as covering the piping with protective materials. If you have any questions, please contact us separately.</li> <li>▶ This valve is structurally dead space. Vaporizing fluids such as hydrogen hydroxide (H<sub>2</sub>O<sub>2</sub>) and soda hypochlorite (NaClO) may vaporize in the dead space and cause an abnormal pressure rise inside the valve. Be very careful. (Gas with abnormal pressure increase due to vaporization is a compressible fluid. Therefore, if a valve should break, fragments will scatter explosively, which is very dangerous.)</li> <li>▶ When conducting a pipe leak test after completion of piping construction, be sure to check with water pressure. Contact us in advance if you are unavoidable to test with a gas.</li> </ul> |

|  <b>Caution</b>     |   |
|--|---|
|  <b>Prohibition</b> | <p><b>The valve can be damaged, or leak.</b></p> <ul style="list-style-type: none"> <li>▶ Do not step on the valve or place heavy objects on it.</li> <li>▶ Keep away from fire and hot objects.</li> <li>▶ Do not use the product in places where it may be submerged.</li> <li>▶ Do not subject the valve to large vibrations.</li> </ul> |

 **Caution**

 **Forcing**


**There is a danger of injury.**

- ▶ Secure sufficient space for maintenance and inspection when piping.

**The valve can be damaged, or leak.**

- ▶ Use the supplied handle or a tool specified by the manufacturer for manual operation.
- ▶ When performing manual operation, make sure that the actuator is not operated by the motor.
- ▶ Secure sufficient space for maintenance and inspection when piping.
- ▶ Check the voltage on the power supply and nameplate before use.
- ▶ Pay attention to the atmosphere where the valve is installed. Avoid locations where the product is exposed to sea breezes, corrosive gases, chemical liquids, sea water, steam, etc.
- ▶ Keep the pressure and temperature of the fluid within the allowable range. (The maximum allowable pressure includes water hammer pressure.)
- ▶ Use a valve of suitable material for the operating conditions. (Depending on the type of chemical liquid, the parts may be damaged. Contact us in advance for details.)
- ▶ Use fluids containing crystalline material under conditions that do not recrystallize.
- ▶ Avoid any place where the valve is constantly exposed to splashes of water and dust, or direct sunlight, or protect the valve with a cover or the like to cover the entire area.
- ▶ Perform maintenance periodically by referring to "11. Inspection items". Pay particular attention to temperature changes and aging during long-term storage or shutdown or use.
- ▶ If internal leakage occurs when the valve is fully closed, adjust the stopper.
- ▶ When installing a valve, provide an appropriate valve support so that excessive force is not applied to the valve and piping.
- ▶ Always use the product within the indicated product specifications.
- ▶ If the valve is used at an intermediate position, the mark of the ball opening will remain on the seat (PTFE), and sealing performance may temporarily deteriorate when the valve is fully closed. Therefore, it is recommended to use the valve fully open or closed.
- ▶ If you notice an unusual odor, heat, or smoke, immediately turn off the power supply. If any abnormality is found, be sure to consult your dealer or us for inspection.
- ▶ Keep the ambient temperature of the installation location within -10 to 50° C.
- ▶ Avoid locations with volatile gases or poor atmospheres. Provide a cover, etc., to cover the entire area.
- ▶ Use clean, dehumidified and deducted operating air. However, please consult with us in advance when using high dry air with a dew point of -40° C or less.

## 3. Name of each part



|      |                              |      |            |      |              |
|------|------------------------------|------|------------|------|--------------|
| [1]  | Body                         | [6]  | Stem       | [13] | Stop ring    |
| [2]  | Ball                         | [7]  | Seat       | [23] | Actuator     |
| [3]  | Carrier                      | [8]  | O-ring (A) | [24] | Stand        |
| [4b] | End connector (Flanged end)  | [9]  | O-ring (B) | [25] | Joint        |
| [4c] | End connector (Socket end)   | [10] | Cushion    | [26] | Bolt (A)     |
| [4d] | End connector (Threaded end) | [11] | O-ring (D) | [27] | Bolt/nut (B) |
| [5]  | Union nut                    | [12] | O-ring (E) | [28] | Screw (B)    |

## 4. Product Specifications



### Model number table

| ACTUATION   | TYPE       | OPERATING SYSTEM | OPERATING SYSTEM                                   | BODY MATERIAL                      | SEAL MATERIAL   | CONNECTION                                      | STANDARD  | SIZE  | HIGH PURITY SERIES /SPACE HEATER   |
|-------------|------------|------------------|--|------------------------------------|-----------------|---|---|---|--|
| A           | 23         | K                | *  | *                                  | *               | *   | *   | * * *   | *  |
| A AUTOMATIC | 23 TYPE 23 | K TYPE TA        | F DOUBLE ACTING<br>G AIR TO OPEN<br>S AIR TO CLOSE | U PVC<br>C C-PVC<br>P PP<br>F PVDF | E EPDM<br>V FKM | S SOCKET<br>N THREADED<br>P SPIGOT<br>F FLANGED | J JIS<br>D DIN<br>1 JIS 10K<br>5 JIS 5K<br>A ANSI | 015 15mm<br>020 20mm<br>025 25mm<br>032 32mm<br>040 40mm<br>050 50mm<br>065 65mm<br>080 80mm<br>100 100mm | BLANK NO LUBRICANT<br>NO SPACE HEATER<br>1 LUBRICANT FREE<br>NO SPACE HEATER<br>0C NO LUBRICANT<br>WITH SPACE HEATER<br>1C LUBRICANT FREE<br>WITH SPACE HEATER |

### NOTE

- JIS standard Socket end of the body material PVDF is not manufactured.
- JIS standard Socket end 32mm with PP body material is not manufactured.
- Connecting method Spigot type is only DIN standard and body material C-PVC is not manufactured.

Relationship between maximum allowable pressure and temperature



**Actuator**
Specifications List

| Operation                   | Size (mm) | Actuator model | Angle adjustment Range    | Operating pressure range MPa {kgf/cm <sup>2</sup> } | Air consumption NL/open/close (0.4MPa) | Air supply port size |
|-----------------------------|-----------|----------------|---------------------------|---|--|----------------------|
| Double action               | 15~25     | TA2A-0402D     | Angle cannot be adjusted. | 0.4~0.7 {4.1~7.1}                                   | 0.5                                    | Rc 1/8               |
|                             | 32~50     | TA2A-050D      | ±5°                       | 0.4~0.7 {4.1~7.1}                                   | 0.9                                    | Rc 1/4               |
|                             | 65, 80    | TA2A-063D      | ±5°                       | 0.4~0.7 {4.1~7.1}                                   | 1.7                                    | Rc 1/4               |
|                             | 100       | TA2A-080D      | ±5°                       | 0.4~0.7 {4.1~7.1}                                   | 3.2                                    | Rc 1/4               |
| Air to open<br>Air to close | 15~25     | TA2A-0402R     | Angle cannot be adjusted. | 0.4~0.7 {4.1~7.1}                                   | 0.8                                    | Rc 1/4               |
|                             | 32~50     | TA2A-050R      | ±5°                       | 0.4~0.7 {4.1~7.1}                                   | 1.7                                    | Rc 1/4               |
|                             | 65, 80    | TA2A-063R      | ±5°                       | 0.4~0.7 {4.1~7.1}                                   | 3.3                                    | Rc 1/4               |
|                             | 100       | TA2A-080R      | ±5°                       | 0.4~0.7 {4.1~7.1}                                   | 6.1                                    | Rc 1/4               |

**5. Optional specifications**


**Limit switch**

| Operation     | Size (mm) | Model code | Protection grade | Limit switch model            |
|---------------|-----------|------------|------------------|-------------------------------|
| Double action | 15~25     | SB2-09     | IP 65 equivalent | V-112-1C24<br>(Made of OMRON) |
| Air to open   | 32~50     | SB2-11     |                  |                               |
| Air to close  | 65~100    | SB2-16     |                  |                               |

Limit switch rating

| Rated voltage | Resistance load (A) | Induction load (A) |
|---------------|---------------------|--------------------|
| 125VAC        | 11                  | 7                  |
| 250VAC        | 11                  | 7                  |
| 125VDC        | 0.5                 | 0.1                |
| 250VDC        | 0.25                | 0.04               |

Internal Circuit Diagram (SW1 is ON)



SW.1 : Contact ①-② is ON when valve right opens (Double action / Air to open)  
 Contact ①-② is ON when valve is left open (Air to close)  
 SW2 : Contact point ③-④ is ON when valve is left open (Double action / Air to open)  
 Contacts ③-④ are ON when valve right opens (Air to close)  
 ※With air piping port facing front

## Solenoid valve

| Operation                                    | Size (mm) | Model code         | Piping port size | Effective area              | Power consumption     | Additional functions   |
|--|-----------|--------------------|------------------|-----------------------------|-----------------------|--|
| Double action<br>Air to open<br>Air to close | 15~100    | 4N3S102K-W□-G31193 | Rc 1/4           | 10mm <sup>2</sup> or higher | AC ; 6VA<br>DC ; 5.5W | <ul style="list-style-type: none"> <li>• Built-in bypass valve</li> <li>• Installation of silencer with throttle valve (used as speed controller)</li> </ul> |


4N3S102K-W□-G31193




| Rated current  | Text entry |
|----------------|------------|
| 100VAC 50/60Hz | 1          |
| 110VAC 50/60Hz | (2)        |
| 200VAC 50/60Hz | 3          |
| 220VAC 50/60Hz | (4)        |
| 24VDC          | 5          |
| 48VDC          | (6)        |
| 100VDC         | (7)        |
| 125VDC         | (8)        |
| 110VDC         | (9)        |

※ () Appended text is a special item.

Wiring diagram




JIS symbol



## Filter-regulator

| Operation                                   | Size (mm) | Model code   | Piping port size | Element filtration rating |
|---|-----------|--------------|------------------|---------------------------|
| Double action<br>Air to open<br>Air to shut | 15~100    | ARU2-02-8A-G | Rc 1/4           | 5 μm                      |


JIS symbol



## Speed controller

| Operation                                    | Size (mm) | Model code | Piping port size | Effective area(mm <sup>2</sup> ) |              | Flow adjustment needle revolution |
|--|-----------|------------|------------------|----------------------------------|--------------|-----------------------------------|
|  |           |            |                  | Free flow                        | Control flow |                                   |
| Double action                                | 15~25     | SC7-06A    | Rc 1/8           | 3.8                              | 5.5          | 8 rotations                       |
| Air to open<br>Air to close                  |           | SC7-08A    | Rc 1/4           | 11                               | 8.3          |                                   |
| Double action<br>Air to open<br>Air to close | 32~100    |            |                  |                                  |              |                                   |

JIS sign



**6. Piping method**

**Flanged end**



|  |   |
|--|---|
|  <b>Warning</b>     |   |
|  <b>Prohibition</b> | <p><b>Serious injury can result.</b></p> <ul style="list-style-type: none"> <li>▶ When hanging or slinging a valve, pay sufficient attention to safety, and do not enter under the load.</li> </ul> |

|  |  |
|--|--|
|  <b>Caution</b>     |  |
|  <b>Prohibition</b> | <p><b>The valve can be damaged, or leak.</b></p> <ul style="list-style-type: none"> <li>▶ Do not overtighten the Union nut.</li> <li>▶ Do not use a pipe wrench to tighten the Union nut.</li> <li>▶ Do not tighten the bolts and nuts for piping to the specified torque values in Table 6-2.</li> </ul>  |
|  <b>Forcing</b>     | <p><b>There is a danger of injury.</b></p> <ul style="list-style-type: none"> <li>▶ Be sure to perform safety inspections of the machine tool and power tool beforehand.</li> <li>▶ Wear appropriate protective equipment according to the type of work being performed.</li> </ul> <p><b>The valve can be damaged, or leak.</b></p> <ul style="list-style-type: none"> <li>▶ Install the product so that excessive stress such as tension, compression, bending or impact is not applied to the piping or valve.</li> <li>▶ Fix the End connector during piping work or disassembly and reassembly.</li> <li>▶ When attaching the valve to the end of the pipe, be sure to attach the Union nut and End connector on the secondary side (downstream side).</li> <li>▶ When connecting to metal piping, do not apply piping stress to the valve.</li> <li>▶ Use a connection flange with a full-face seat.</li> <li>▶ Check that there is no difference in mutual flange standards.</li> <li>▶ Be sure to use sealing gaskets (AV Gasket) between the flanges, and tighten the pipe bolts/nuts to the specified torque values in Table 6-2 "Flange tightening torque values." (When other than AV Gasket, the tightening torque value will change.)</li> <li>▶ The misalignment and parallelism of the flange surface should be less than the values given in "Table 6-1 Axis misalignment and parallelism".</li> <li>▶ Tighten the bolts and nuts for piping diagonally to the specified torque values in Table 6-2.</li> </ul> |

- Preparations ▶ Torque Wrench ▶ Belt Wrench ▶ Spanner or Ophthalmic Wrench  
 ▶ Pipe head bolts/nuts, washers ▶ AV Gasket ▶ cloth

**[Procedure]**

- 1) Clean mutual flange surfaces with a waste cloth.
- 2) Set AV Gasket between the flanges.
- 3) Insert the washer and bolt from the connecting flange side, insert the washer and nut from the valve side, and tighten temporarily by hand.
- 4) Set the axis misalignment and parallelism of the flange surface below the values shown in Table 6-1, "Axis misalignment and parallelism." (See Fig. 6-1.)
- 5) Using a torque wrench, gradually tighten the screws diagonally until they reach the specified torque value in Table 6-2. (See Fig. 6-2.)
- 6) Tighten it more than two turns clockwise with "Table 6-2 Flange Tightening Torque Specified Values". (See Fig. 6-2.)
- 7) When it is necessary to loosen or remove the Union nut for construction reasons, follow the procedure below to tighten the Union nut.
  - 7-1) Make sure that the O-ring (A) is installed in the body correctly.
  - 7-2) Bring the End connector and Union nut into contact with the body side so that the O-ring (A) does not come off.
  - 7-3) Tighten the Union nut by hand until it is tight.
  - 7-4) Screw in the Union nut by 1/4 to 1/2 turn with a belt wrench to prevent damage to the Union nut.




**Table 6-1**  
Axis misalignment and parallelism

| Size  | Shaft misalignment | Parallelism (a-b) |
|-------|--------------------|-------------------|
| 15mm  | 1.0 mm             | 0.5 mm            |
| 20mm  |                    |                   |
| 25mm  |                    |                   |
| 32mm  |                    |                   |
| 40mm  | 1.0 mm             | 0.8 mm            |
| 50mm  |                    |                   |
| 65mm  |                    |                   |
| 80mm  |                    |                   |
| 100mm | 1.0 mm             | 1.0 mm            |

**Table 6-2 Flange tightening torque**

| Size  | PTFE coating | PVDF coating | Rubber   |
|-------|--------------|--------------|----------|
| 15mm  | 17.5 N-m     | 17.5 N-m     | 8.0 N-m  |
| 20mm  |              |              |          |
| 25mm  | 20.0 N-m     | 20.0 N-m     | 20.0 N-m |
| 32mm  |              |              |          |
| 40mm  |              |              |          |
| 50mm  | 22.5 N-m     | 22.5 N-m     | 22.5 N-m |
| 65mm  |              |              |          |
| 80mm  | 30.0 N-m     | 30.0 N-m     | 30.0 N-m |
| 100mm |              |              |          |



Threaded end

|                      |   |
|----------------------|---|
| <b>⚠ Warning</b>     |   |
| <b>🚫 Prohibition</b> | <p><b>Serious injury can result.</b></p> <ul style="list-style-type: none"> <li>▶ When hanging or slinging a valve, pay sufficient attention to safety, and do not enter under the load.</li> </ul> |

|                      |  |
|----------------------|--|
| <b>⚠ Caution</b>     |  |
| <b>🚫 Prohibition</b> | <p><b>The valve can be damaged, or leak.</b></p> <ul style="list-style-type: none"> <li>▶ Do not overtighten the screws at the joints.</li> <li>▶ Do not overtighten the Union nut.</li> <li>▶ Do not use a pipe wrench to tighten the Union nut.</li> </ul> |



|                  |   |
|------------------|---|
| <b>! Forcing</b> | <p><b>There is a danger of injury.</b></p> <ul style="list-style-type: none"> <li>▶ Be sure to perform safety inspections of the machine tool and power tool beforehand.</li> <li>▶ Wear appropriate protective equipment according to the type of work being performed.</li> </ul> <p><b>The valve can be damaged, or leak.</b></p> <ul style="list-style-type: none"> <li>▶ The Union nut of this product is lightly tightened to make it easier to loosen. Be sure to remove the End connector before installation.</li> <li>▶ Install the product so that excessive stress such as tension, compression, bending or impact is not applied to the piping or valve.</li> <li>▶ Fix the End connector during piping work or disassembly and reassembly.</li> <li>▶ When attaching the valve to the end of the pipe, be sure to attach the Union nut and End connector on the secondary side (downstream side).</li> <li>▶ When connecting to metal piping, do not apply piping stress to the valve.</li> <li>▶ Make sure that the screws at the joints are made of resin.</li> <li>▶ Use sealing tape for the sealing material of the screw-in part. If liquid sealant or liquid gasket is used, stress cracking (environmental stress cracking) may occur.</li> </ul> |
|------------------|---|

|   |  |
|---|--|
| <p><b>Safe use.</b></p> <ul style="list-style-type: none"> <li>▶ When installing the valve at the end of the pipe, pay attention to the flow direction. (Check ▲ mark on the body of the Carrier side. The Carrier part of the secondary side (downstream side) is integrated with the body, so if it is installed at the end of the pipe, it will be safer to use.)</li> </ul> |  |
|---|--|

Preparations ▶ Sealing tape ▶ Belt Wrench ▶ Spanner or an eyeglass wrench

**[Procedure]**

- 1) Wrap sealing tape around the male thread of the Joint, leaving approximately 3mm at the end.
- 2) Loosen the Union nut by hand.
- 3) Remove the Union nut and End connector from the body.
- 4) Tighten the male thread of the Joint and the End connector until tight.
- 5) Screw in with a wrench or a motor wrench 1/2 to 1 turn to prevent damage to the End connector.
- 6) Check that the O-ring (A) is correctly installed in the body.
- 7) Bring the End connector and Union nut into contact with the body side so that the O-ring (A) does not come off.
- 8) Tighten the Union nut by hand until it is tight.
- 9) Screw in the Union nut by 1/4 to 1/2 turn with a belt wrench to prevent damage to the nut.



Socket end (adhesive)


|  <b>Warning</b>     |   |
|--|---|
|  <b>Prohibition</b> | <p><b>Serious injury can result.</b></p> <ul style="list-style-type: none"> <li>▶ When hanging or slinging a valve, pay sufficient attention to safety, and do not enter under the load.</li> </ul> <p><b>Fire or an explosion can result.</b></p> <ul style="list-style-type: none"> <li>▶ Ensure adequate ventilation when using adhesives and do not use open flames around them.</li> </ul> |

|  <b>Caution</b>     |   |
|--|---|
|  <b>Prohibition</b> | <p><b>There is a danger of injury.</b></p> <ul style="list-style-type: none"> <li>▶ The adhesive contains volatile solvents, so do not inhale odors directly.</li> </ul> <p><b>The valve can be damaged, or leak.</b></p> <ul style="list-style-type: none"> <li>▶ Do not apply too much adhesive. Excessive adhesive will flow into the valve.</li> <li>▶ Do not strike the pipe when inserting it into the End connector.</li> <li>▶ Do not overtighten the Union nut.</li> <li>▶ Do not use a pipe wrench to tighten the Union nut.</li> </ul>   |
|  <b>Forcing</b>   | <p><b>There is a danger of injury.</b></p> <ul style="list-style-type: none"> <li>▶ Be sure to perform safety inspections of the machine tool and power tool beforehand.</li> <li>▶ Wear appropriate protective equipment according to the type of work being performed.</li> <li>▶ If the adhesive adheres to the skin, remove it immediately.</li> <li>▶ If you feel worse or feel unusual when using the adhesive, promptly seek a doctor's diagnosis and take appropriate action.</li> </ul> <p><b>The valve can be damaged, or leak.</b></p> <ul style="list-style-type: none"> <li>▶ The Union nut of this product is lightly tightened to make it easier to loosen. Be sure to remove the End connector before installation.</li> <li>▶ Install the product so that excessive stress such as tension, compression, bending or impact is not applied to the piping or valve.</li> <li>▶ Fix the End connector during piping work or disassembly and reassembly.</li> <li>▶ When attaching the valve to the end of the pipe, be sure to attach the Union nut and End connector on the secondary side (downstream side).</li> <li>▶ Be careful when constructing under low temperature, as solvent vapor is less likely to evaporate and tends to remain.</li> <li>▶ After piping, open both ends of the pipe and use a blower (low-pressure type) to ventilate to remove the solvent vapor.</li> <li>▶ Use "AV Cement" depending on the material.</li> <li>▶ Perform the water flow test after 24 hours or more have elapsed after completion of bonding.</li> </ul> |



Socket end, Spigot end (Fusing)

|                      |   |
|----------------------|---|
| <b>⚠ Warning</b>     |   |
| <b>🚫 Prohibition</b> | <p><b>Serious injury can result.</b></p> <ul style="list-style-type: none"> <li>▶ When hanging or slinging a valve, pay sufficient attention to safety, and do not enter under the load.</li> </ul> |

|                      |  |
|----------------------|--|
| <b>⚠ Caution</b>     |  |
| <b>🚫 Prohibition</b> | <p><b>The valve can be damaged, or leak.</b></p> <ul style="list-style-type: none"> <li>▶ Do not overtighten the Union nut.</li> <li>▶ Do not use a pipe wrench to tighten the Union nut.</li> </ul>   |
| <b>! Forcing</b>     | <p><b>There is a danger of injury.</b></p> <ul style="list-style-type: none"> <li>▶ Be sure to perform safety inspections of the machine tool and power tool beforehand.</li> <li>▶ Wear appropriate protective equipment according to the type of work being performed.</li> </ul> <p><b>The valve can be damaged, or leak.</b></p> <ul style="list-style-type: none"> <li>▶ The Union nut of this product is lightly tightened to make it easier to loosen. Be sure to remove the End connector before installation.</li> <li>▶ Install the product so that excessive stress such as tension, compression, bending or impact is not applied to the piping or valve.</li> <li>▶ Fix the End connector during piping work or disassembly and reassembly.</li> <li>▶ When attaching the valve to the end of the pipe, be sure to attach the Union nut and End connector on the secondary side (downstream side).</li> </ul> |
|                      | <p><b>Safe use.</b></p> <ul style="list-style-type: none"> <li>▶ When installing the valve at the end of the pipe, pay attention to the flow direction. (Check ▲ mark on the body of the Carrier side. The Carrier part of the secondary side (downstream side) is integrated with the body, so if it is installed at the end of the pipe, it will be safer to use.)</li> </ul> <div style="text-align: right;">  </div>   |

|              |                                       |                  |
|--------------|---------------------------------------|------------------|
| Preparations | ▶ Belt Wrench                         | ▶ Fusing machine |
|              | ▶ User's manual of the fusing machine |                  |

**[Procedure]**

- 1) Loosen the Union nut by hand.
- 2) Remove the Union nut and End connector from the body.
- 3) Pass the Union nut to the pipe side.
- 4) From here, please refer to the User's manual of the welding machine for welding.
- 5) Check that the O-ring (A) is correctly installed in the body.
- 6) Bring the End connector into contact with the body so that the O-ring (A) does not come off.
- 7) Tighten the Union nut by hand until it is tight.
- 8) Screw in the Union nut by 1/4 to 1/2 turn with a belt wrench to prevent damage to the nut.



Support of the product

|  <b>Caution</b>     |  |
|--|--|
|  <b>Prohibition</b> | <p><b>The valve can be damaged, or leak.</b></p> <ul style="list-style-type: none"> <li>▶ Do not over-tighten when supporting piping with a U-band, etc.</li> <li>▶ When installing a valve in the piping around the pump, do not cause large vibrations in the valve.</li> </ul>  |
|  <b>Forcing</b>     | <p><b>There is a danger of injury.</b></p> <ul style="list-style-type: none"> <li>▶ Be sure to perform safety inspections of the machine tool and power tool beforehand.</li> <li>▶ Wear appropriate protective equipment according to the type of work being performed.</li> </ul> <p><b>The valve can be damaged, or leak.</b></p> <ul style="list-style-type: none"> <li>▶ Do not over-tighten when supporting piping with a U-band, etc.</li> <li>▶ When installing the product, make sure that no excessive stress such as tension, compression, bending or impact is applied to the piping or valve.</li> <li>▶ The Union nut of this product is lightly tightened to make it easier to loosen. Be sure to remove the End connector before installation. (There is a risk of external leakage.)</li> <li>▶ Fix the End connector during piping installation or disassembly and reassembly.</li> <li>▶ Be sure to attach the Union nut and End connector on the secondary side (downstream side) when attaching to the end of the piping line.</li> <li>▶ When connecting a resin valve to metal piping, make sure that no piping stress is applied to the resin valve.</li> <li>▶ Make sure that the screws at the joints are made of resin.</li> <li>▶ Use sealing tape for the thread joints of our resin piping materials.</li> <li>▶ When installing the valve at the end of the pipe, pay attention to the flow direction. (The Carrier body is marked with ◀ and should be checked. On the secondary side (downstream side), the Carrier part is integrated with the main body. Attaching the Carrier part to the end of the pipe. Matching and safer use)</li> <li>▶ Install it vertically when screwing in the Ensats.</li> <li>▶ For detailed handling of the special tool for installation of the entertainment, refer to the User's manual of the entertainment manufacturer separately.</li> </ul> |

Preparations ▶ Spanner ▶ U-band (with bolt) ▶ Rubber seat


## Horizontal piping

- 1) Lay a rubber sheet on the pipe and secure it with the U-band.
- 2) If the actuator is on the underside, place a rubber sheet on the actuator and install the frame.



## Vertical piping

- 1) Place a rubber sheet on the actuator and install the frame.
- 2) Lay a rubber sheet on the pipe and secure it with the U-band.



**7. Air piping method**

Without option or with speed controller

|  |   |
|--|---|
|  <b>Warning</b>     |   |
|  <b>Prohibition</b> | <p><b>There is a danger of injury.</b></p> <ul style="list-style-type: none"> <li>▶ Do not remove the protective plug until just before connecting the air piping.</li> </ul> |



|  |   |
|--|---|
|  <b>Caution</b>     |   |
|  <b>Prohibition</b> | <p><b>Damage may occur.</b></p> <ul style="list-style-type: none"> <li>▶ Do not over-tighten the Joint for air piping.</li> </ul>   |
|  <b>Forcing</b>     | <p><b>There is a danger of injury.</b></p> <ul style="list-style-type: none"> <li>▶ Wear appropriate protective equipment according to the type of work being performed.</li> </ul> <p><b>The valve can be damaged, or leak.</b></p> <ul style="list-style-type: none"> <li>▶ Confirm the connection location, air piping size, and screw type from the approval delivery drawing etc. of the product, and then connect the air piping.</li> <li>▶ Use clean, dehumidified and dust-free air. Consult with CKD when using high dry air with a dew point of -40° C or less.</li> <li>▶ When using at an ambient temperature of 5° C or less, remove moisture from the operation air to prevent freezing.</li> <li>▶ When using copper piping for air piping, use one with rust-proof treatment on the inner surface of the pipe.</li> <li>▶ Flush the inside of the air piping thoroughly before connecting the air piping.</li> <li>▶ When connecting the air piping, be careful that foreign matter, such as sealant, does not enter the piping.</li> <li>▶ Be sure to remove burrs from the pipe Joints/threads.<br/>(This may cause gargle or air leakage.)</li> </ul> |

|              |                                 |                |
|--------------|---------------------------------|----------------|
| Preparations | ▶ Copper or tube for air piping | ▶ Wrench       |
|              | ▶ Copper or tube Joints         | ▶ Sealing tape |

**[Procedure]**

- 1) Wrap sealing tape around the male thread of the Joint, leaving approximately 3mm at the end.
- 2) Tighten the Joint to the piping port of the actuator with a Joint.
- 3) Screw the Joint in one turn with a wrench.
- 4) Install copper or tube tubes for air piping.

※Although the picture shows no speed controller, the piping procedure is the same for those with speed controller.



## With solenoid valve and filter regulator



|  <b>Warning</b>     |   |
|--|---|
|  <b>Prohibition</b> | <p><b>There is a danger of injury.</b></p> <ul style="list-style-type: none"> <li>▶ Do not remove the protective plug until just before connecting the air piping.</li> </ul> |

|  <b>Caution</b>     |  |
|--|--|
|  <b>Prohibition</b> | <p><b>Damage may occur.</b></p> <ul style="list-style-type: none"> <li>▶ Do not over-tighten the Joint for air piping.</li> </ul>  |
|  <b>Forcing</b>     | <p><b>The valve can be damaged, or leak.</b></p> <ul style="list-style-type: none"> <li>▶ When using steel pipes for air piping, use the inner surface of the pipe treated with anti-rust treatment.</li> <li>▶ Flush the inside of the air piping thoroughly before connecting the air piping.</li> <li>▶ When connecting the air piping, be careful that foreign matter, such as sealant, does not enter the piping.</li> <li>▶ Be sure to remove burrs on the threads of the pipe Joints.<br/>(This may cause galling or air leakage.)</li> <li>▶ Do not over-tighten the Joint for air piping.</li> <li>▶ Be sure to lock the adjustment knob of the solenoid valve after adjustment.</li> <li>▶ Regularly drain the drain from the filter regulator.</li> <li>▶ Set the secondary side pressure of the filter regulator to a setting that meets the equipment specifications.<br/>(It may cause malfunction or failure.)</li> </ul> |

|              |                                 |                         |
|--------------|---------------------------------|-------------------------|
| Preparations | ▶ Copper or tube for air piping | ▶ Copper or tube Joints |
|              | ▶ Sealing tape                  | ▶ Wrench                |

**[Procedure]**

- 1) Wrap sealing tape around the male thread of the Joint, leaving approximately 3mm at the end.
- 2) Tighten the Joint to the air piping port.
- 3) Screw the Joint in one turn with a wrench.
- 4) Install copper or tube tubes for air piping.



**8. Wiring method**

Limit switch


|  |   |
|--|---|
|  <b>Warning</b>     |   |
|  <b>Prohibition</b> | <p><b>There is a risk of electric shock.</b></p> <ul style="list-style-type: none"> <li>▶ Do not perform wiring while the power is on.</li> </ul> |

|  |  |
|--|--|
|  <b>Caution</b>     |  |
|  <b>Prohibition</b> | <p><b>Otherwise failure or malfunction of the machine can result.</b></p> <ul style="list-style-type: none"> <li>▶ If the product is installed outdoors or in a location where there is a possibility of rainwater or moisture intrusion, make sure that rainwater, etc. does not enter through the wiring port.</li> </ul>  |
|  <b>Forcing</b>     | <p><b>There is a danger of injury.</b></p> <ul style="list-style-type: none"> <li>▶ Be sure to perform safety inspections of the machine tool and power tool beforehand.</li> <li>▶ Wear appropriate protective equipment according to the type of work being performed.</li> </ul> <p><b>Otherwise failure or malfunction of the machine can result.</b></p> <ul style="list-style-type: none"> <li>▶ Connect the wires using solderless terminals with insulation covering so that they do not come into contact with the cover or housing.<br/>(If the crimp terminal comes into contact with the cover, the cover may not close and may cause a ground fault.)</li> <li>▶ Contact CKD when using a limit switch in a 1mA~100mA, 5V~30V.</li> </ul> |

|              |                          |                    |
|--------------|--------------------------|--------------------|
| Preparations | ▶ Phillips screwdriver   | ▶ Connector (G1/2) |
|              | ▶ Flat-blade screwdriver | ▶ Wire stripper    |

## [Procedure]

- 1) Remove the pointer by hand.
- 2) Loosen the four screws securing the lid with a Phillips screwdriver to remove it.  
※Do not lose the O-ring.
- 3) Turn the pipe port protection cap counterclockwise to remove it.
- 4) Pass the cable through the connector.
- 5) Peel off the outer skin of the cable with a wire stripper.
- 6) Wire the terminal screw with a flat-blade screwdriver according to the internal circuit diagram on page 13.
- 7) Tighten the connector to secure the cable.
- 8) After attaching the lid, tighten the screws (4 locations) alternately and evenly with a Phillips screwdriver.  
※Do not forget the O-ring when attaching the lid. (There is a risk of electric leakage or electric shock.)
- 9) Insert the pointer so that the direction of the seal arrow on the camshaft head matches the direction of the pointer.



## Solenoid valve

### Warning



#### Prohibition

**There is a risk of electric shock.**

- ▶ Do not connect or separate lines to the solenoid valves while the power is on.
- ▶ Do not perform any work with wet hands or tools.

### Caution



#### Forcing

**There is a danger of injury.**

- ▶ Be sure to perform safety inspections of the machine tool and power tool beforehand.
- ▶ Wear appropriate protective equipment according to the type of work being performed.

**Otherwise, the machine may malfunction.**

- ▶ Be sure to lock the adjustment knob of the solenoid valve after adjustment.

|              |                        |                          |
|--------------|------------------------|--------------------------|
| Preparations | ▶ Phillips screwdriver | ▶ Terminal crimping tool |
|              | ▶ Connector (G1/2)     | ▶ Wire stripper          |

**[Procedure]**

1) Loosen the cover setscrew with a Phillips screwdriver and remove the cover.

|                  |  |
|------------------|--|
| <b>⚠ Caution</b> |  |
| <b>! Forcing</b> | <b>Failure to do so may result in an electric leakage or electric shock.</b> |
|                  | ▶ Do not lose the O-ring.  |

2) Pull out the Faston terminal and insulation cover inserted in the coil side.  
 ※The grounding terminal is not provided with an insulation cover.

3) Pass the cables in the order of the connector and cover.

4) Peel off the outer skin of the cable with a wire stripper.




5) Pass the lead wire through the insulation cover.

6) Attach the Faston terminal to the lead wire with a terminal crimping tool.

7) Insert the Faston terminal into the coil side terminal and put the insulation cover on.

8) Attach the cover by tightening the cover set screw with a Phillips screwdriver.  
 The cover can be attached with the wiring lead-out port at either top or bottom.

9) Tighten the cable with the connector.



## 9. Commissioning method

### Manual Operation <Double action>



|  |   |
|--|---|
|  <b>Warning</b>     |   |
|  <b>Prohibition</b> | <p><b>Serious injury can result.</b></p> <ul style="list-style-type: none"> <li>▶ Do not supply air during manual operation.</li> </ul> |

|  |   |
|--|---|
|  <b>Caution</b>     |   |
|  <b>Prohibition</b> | <p><b>You may be electrocuted or injured.</b></p> <ul style="list-style-type: none"> <li>▶ For models with solenoid valves, do not leave the solenoid valve terminal cover removed.</li> <li>▶ Keep hands free of moisture and oil during operation.</li> </ul> |
|  <b>Forcing</b>     | <p><b>Doing so may damage the machine.</b></p> <ul style="list-style-type: none"> <li>▶ Do not turn the manual override further than necessary from the fully open/closed positions.</li> </ul>   |

Preparations ▶ Lever-handle for TA (sold separately) or wrench

**[Procedure]**

- 1) Close the main valve of the operation air and turn off the power of the solenoid valve.
- 2) Turn the knob of the bypass valve counterclockwise to exhaust the air in the actuator.
- 3) Fit TA handle or wrench to the upper output shaft of the actuator and operate it while looking at the valve travel indicator.  
 Clockwise; left open direction  
 Counterclockwise; right opening direction
- 4) Return to the condition prior to manual override (right or left open) and remove the lever handle for TA or the wrench from the upper output shaft of the actuator.
- 5) Close the bypass valve by turning the knob of the bypass valve clockwise.
- 6) Open the main valve of the operation air to supply air to the solenoid valve.



## Manual operation <Single acting>

### Warning



**Prohibition**

**Serious injury can result.**


▶ Do not supply air during manual operation.

Preparations : ▶ Dedicated manual handle unit (optional installation) ▶ Wrench

| Size     | Manual override (optional) |
|----------|----------------------------|
| 15~25mm  | Not possible               |
| 32~100mm | Possible                   |

### [Procedure]

- 1) Close the main valve of the operation air and turn off the power of the solenoid valve.
- 2) Turn the knob of the bypass valve counterclockwise to exhaust the air in the actuator.
- 3) Loosen the lock nut (small) with a wrench.



### Caution



**Prohibition**


**The stopper may change position and leak.**

▶ The lock nut (large) is for adjusting the right-open and left-open stoppers. Do not loosen it.

- 4) Turn the round handle while observing the opening finger gauge.

| Round handle rotation direction | Air to open             | Air to close            |
|---------------------------------|-------------------------|-------------------------|
| Clockwise                       | Left open direction     | Right opening direction |
| Counterclockwise                | Right opening direction | Left open direction     |

| Size               | 15~50mm              | 65~100mm             |
|--------------------|----------------------|----------------------|
| Handle revolutions | About 24 revolutions | About 27 revolutions |



- 5) Return to the condition before manual operation (right or left open) and tighten the lock nut (small) with a wrench.
- 6) Close the bypass valve by turning the knob of the bypass valve clockwise.
- 7) Open the main valve of the operation air to supply air to the solenoid valve.

## Air Operation

### Warning



**Forcing**

**Serious injury can result.**

- ▶ Check that the spanner for manual operation is not mated with the upper output shaft of the actuator.

### Caution



**Prohibition**


**Otherwise, the valve may be damaged, or inoperative.**

- ▶ Use the product within the indicated product specifications.

#### [Procedure]

- 1) Supplies air to the air piping port.
- 2) Check that the air supply side and the display position match.  
(Refer to the figure below for the display status.)
- 3) Stop the air supply.

#### Standard (View with air piping port facing front)




<For models with solenoid valve>

#### [Procedure]


- 1) Supplies air to the solenoid valve.
- 2) Check that the operation shown in the table below is achieved by pressing the pushbutton below the solenoid valve terminal cover with your finger.
- 3) Confirm that the operation shown in the table below is achieved by energizing or de-energizing the solenoid valve.
- 4) Turn off the power to the solenoid valve.

#### With limit switch box

(The figure shows the air piping port facing front.)



|              |               |                              |              |
|--------------|---------------|------------------------------|--------------|
| Push button  | Power supply  | Double action<br>Air to open | Air to close |
| Press        | Energizing    | Right open                   | Left open    |
| Do not press | De-energizing | Left open                    | Right open   |



## Adjusting the Opening/Closing Speed <Double action>

### Caution



**Prohibition**



**Otherwise damage to the solenoid valve or malfunction can result.**

- ▶ Be sure to lock the adjustment knob of the solenoid valve after adjustment.  
(Do not tighten the lock nut with excessive force.)

Preparations : ▶ Wrench

### [Procedure]

- 1) Supplies air to the solenoid valve.
- 2) Hold the adjustment knob of both left-open and right-open speed controllers with your fingers, and turn the lock nut counterclockwise with a spanner to release the adjustment knob.
- 3) Open left and right Turn both adjustment knobs clockwise until they do not turn.
- 4) Energize the solenoid valve to open the valve to the right.
- 5) Turn the adjustment knob of the right open side speed controller counterclockwise little by little.
- 6) Turn off the power to the solenoid valve and open the valve to the left.
- 7) Turn the adjustment knob of the left open side speed controller counterclockwise little by little.
- 8) Repeat steps 4) to 7) to set the opening/closing speed to the desired one.
- 9) Hold the adjustment knob of both left-open and right-open speed controllers with your fingers, and turn the lock nut clockwise with a spanner to secure the adjustment knob.



**Opening/Closing Speed Adjustment Method <Single Action>**



|                      |  |
|----------------------|--|
| <b>⚠ Caution</b>     |  |
| <b>⊘ Prohibition</b> | <p><b>Otherwise damage to the solenoid valve or malfunction can result.</b></p> <p>▶ Be sure to lock the adjustment knob of the solenoid valve after adjustment.<br/>(Do not tighten the lock nut with excessive force.)</p> |

The direction in which the speed can be adjusted differs depending on the operating model.

| Actuation type    | Speed at which the right opens | Speed of opening to the left |
|-------------------|--------------------------------|------------------------------|
| Air to open type  | Not adjustable                 | Can be adjusted              |
| Air to close type | Can be adjusted                | Not adjustable               |

**[Procedure]**

- 1) Supplies air to the solenoid valve.
- 2) While holding the speed controller adjustment knob with your finger, turn the lock nut counterclockwise with a spanner to release the adjustment knob.
- 3) Turn the adjustment knob clockwise until it no longer turns.
- 4) Energize the solenoid valve to open the valve to the right for air to open and open the valve to the left for air to close.
- 5) Turn the speed controller adjustment knob counterclockwise little by little.
- 6) Turn off the power to the solenoid valve. Open left for air to open and open right for air to close.
- 7) Repeat steps 4) to 6) to set the opening/closing speed to the desired one.
- 8) While holding the speed controller adjustment knob with your finger, secure the adjustment knob by turning the lock nut clockwise with a spanner.



## How to adjust the surface pressure of the ball and seat

If internal leakage (seat leakage) occurs when the valve is fully closed, tightening the Carrier may improve seat leakage.

If tightening the Carrier does not improve the seat leakage, replace the valve according to section 10 "Disassembly/Assembly Method for Replacement of Parts".



|  <b>Caution</b>     |   |
|--|---|
|  <b>Prohibition</b> | <p><b>The valve can be damaged, or leak.</b></p> <ul style="list-style-type: none"> <li>▶ Do not overtighten the Carrier.</li> <li>▶ Do not overtighten the Union nut.</li> <li>▶ Do not use a pipe wrench to tighten the Union nut.</li> </ul> |
|  <b>Forcing</b>     | <p><b>There is a danger of injury.</b></p> <ul style="list-style-type: none"> <li>▶ A little fluid remains in the valve. Wear protective gloves and eye protection.</li> </ul>  |

- ▶ Belt wrench ▶ wrench ▶ handle (hand wheel for manual override sold separately)
- Preparations
- ▶ Protective gloves and goggles

### <Surface pressure adjustment>

#### [Procedure]

- 1) Zero the pressure in the piping to completely drain the fluid.
- 2) Turn off the power of the solenoid valve. The double action and air to open are set to left open, and the air to close is set to right open.
- 3) Loosen the three Union nuts with a belt wrench.
- 4) Remove the valve from the piping.
- 5) Record the position of the ball [2] as viewed from AV marking on the body [1] and the orientation of the actuator. (important when assembling)
- 6) Loosen and remove the screws (B) [27] between the mounting bracket [24] and the body [1], and remove the mounting bracket [24] and the actuator [23].
- 7) Remove the O-ring (A) [8] on the Carrier.
- 8) The convex part of the upper part of the manual handle is fitted into the concave part of the Carrier on the right opening side for the air to open and the left opening side for the air to close, and the surface pressure is adjusted by rotating the Carrier.
- 9) Attach the manual override to the stem and turn the hand wheel 180°. The double action and air to open are set to the right open position and the forward operation is set to the left open position.
- 10) Remove the manual handle from the valve.
- 11) The convex part of the upper part of the handle for manual operation is fitted into the concave part of the Carrier on the left opening side for the air to open and the right opening side for the air to close, and the surface pressure is adjusted by rotating the Carrier.
- 12) Attach the manual handle to the stem and check that manual operation can be smoothly performed.



### <Assembly>

#### [Procedure]

- 1) Follow the steps from step 7) in <Surface pressure adjustment> in the reverse order.

**10. How to disassemble/assemble parts for replacement**

If internal leakage (seat leakage) or external leakage occurs when the valve is fully closed, the leakage may be improved by replacing the parts.

If the leak does not improve after replacing the parts, remove and replace the valve according to this item.

|  <b>Warning</b> |   |
|--|---|
|  <b>Forcing</b> | <p><b>There is a danger of injury.</b></p> <ul style="list-style-type: none"> <li>▶ Be sure to perform safety inspections of the machine tool and power tool beforehand.</li> <li>▶ Wear appropriate protective equipment according to the type of work being performed.</li> </ul> |


|  <b>Caution</b>     |  |
|--|--|
|  <b>Prohibition</b> | <p><b>Damage may occur.</b></p> <ul style="list-style-type: none"> <li>▶ When replacing the valve or replacing parts, completely drain the fluid from the piping to reduce the fluid pressure to zero.</li> <li>▶ Do not over tighten the Union nut.</li> <li>▶ Do not use a pipe wrench when tightening the Union nut.</li> </ul>   |
|  <b>Forcing</b>   | <p><b>Damage may occur.</b></p> <ul style="list-style-type: none"> <li>▶ Fix the End connector during piping installation or disassembly and reassembly.</li> <li>▶ Be sure to confirm that the Union nut is fully tightened before the water flow test.</li> <li>▶ Tighten the Union nut paying attention to the shaft center misalignment and face-to-face dimension.</li> <li>▶ When connecting a resin valve to metal piping, be careful not to apply piping stress to the resin valve.</li> </ul> |

- Preparations ▶ Belt Wrench ▶ Hex Wrench ▶ Spanner ▶ Protective Gloves  
 ▶ Protective spectacle ▶ handle (manual override handle sold separately)

### <Disassembly>

#### [Procedure]



- 1) Zero the pressure in the piping to completely drain the fluid.
- 2) Turn off the power of the solenoid valve. The double action and air to open are set to left open, and the air to close is set to right open.
- 3) Loosen the three Union nuts with a belt wrench.
- 4) Remove the valve from the piping.
- 5) Record the position of the ball [2] as viewed from AV marking on the body [1] and the orientation of the actuator. (important when assembling)
- 6) Loosen and remove the screws (B) [27] between the mounting bracket [24] and the body [1], and remove the mounting bracket [24] and the actuator [23].
- 7) Remove the O-ring (A) [8] on the Carrier.
- 8) Mate the convex part on the upper part of the hand handle with the concave part of the Carrier.
- 9) Turn the hand handle counterclockwise to remove the Carrier.
- 10) Remove the seat, O-ring (B) and O-ring (C) (65mm or more) from the Carrier to prevent scratching.
- 11) Push out the ball by hand.
- 12) Push the stem from the top flange side to the body side.
- 13) Remove the O-rings (D) and (E) from the stem, taking care not to damage them.



### <Disassembly>

#### [Procedure]

- 1) Assemble in reverse order from step 13) of <Disassembly>.
  - ※ When attaching the seat, check the front and back sides of the seat before attaching it.



**11. Inspection item**

|  <b>Caution</b> |   |
|--|---|
|  <b>Forcing</b> | <p><b>Fluid may leak from the valve or the actuator may fail.</b></p> <ul style="list-style-type: none"> <li>▶ Maintenance should be performed every 3 to 6 months as a guide in order to keep the watch in normal condition and use it for a long time. Pay particular attention to temperature changes and aging during long-term storage or shutdown or use.</li> </ul> <p><b>There is a danger of injury.</b></p> <ul style="list-style-type: none"> <li>▶ When removing the valve from the piping when replacing the valve or parts, completely remove the fluid from the piping before starting work.</li> <li>▶ If any trouble is found, take the appropriate action referring to "<b>12. Cause of malfunction and remedy.</b>"</li> </ul> |

**Daily inspection**

| Inspection items and inspection methods   | Guideline of judgment | Check point  | Treatment method  |
|---|-----------------------|--|---|
| External leakage (visual inspection)      | No leakage            | [Flanged end]<br>Pipe flange connection              | ① Retighten the pipe bolts to the specified torque.<br>② Remove the valve from the pipe and retighten the pipe bolts.<br>(Ref: 6. Piping method [Flanged end])    |
|   |                       | [Socket end]<br>Adhesive construction section        | Remove the valve from the piping and retry the bonding process.<br>(Ref: 6. Piping method [Socket end])   |
|   |                       | [Threaded end]<br>Threaded connection                | Remove the valve from the piping and screw the valve in again.<br>(Ref: 6. Piping method [Threaded end])  |
|   |                       | Top flange of the valve                              | Remove the valve from the piping and replace the valve or defective part.<br>(Ref: 10.How to disassemble/assemble for parts replacement)                          |
|   |                       | Union nut portion of the valve                       | ① Retighten the Union nut<br>② Remove the valve from the piping, check the O-ring and sealing surface, and replace the defective part.<br>(Ref: 6. Piping method) |
|   |                       | Surface of the entire valve                          | Remove the valve from the pipe and replace the valve.<br>(Ref: 10.How to disassemble/assemble for parts replacement)  |
| Internal leakage (visual and measurement) | No leakage            | Leakage to secondary side when valve is fully closed | Remove the valve from the piping and replace the valve or defective part.<br>(Ref: 10.How to disassemble/assemble for parts replacement)                          |
|   |                       | Measured values of flowmeters, pressure gauges, etc. | Remove the valve from the piping and replace the valve or defective part.<br>(Ref: 10.How to disassemble/assemble for parts replacement)                          |

| Inspection items and inspection methods | Guideline of judgment | Check point             | Treatment method   |
|---|-----------------------|-------------------------|--|
| Abnormal noise (hearing)                | No abnormal noise     | Valves and actuators    | Remove the valve from the pipe and replace the valve or actuator.<br><a href="#">(Ref: 10.How to disassemble/assemble for parts replacement)</a> |
|   |                       | Piping around the valve | Reconfirm the conditions of use<br><a href="#">(Ref: 2. Safety Instructions)</a>   |

**Periodic inspection**
**●Guideline for the inspection cycle: 3 months**

| Inspection items and inspection methods | Guideline of judgment          | Check point             | Remedy for malfunctions  |
|---|--------------------------------|-------------------------|--|
| Vibration (palpation)                   | No difference from other parts | Valves and actuators    | Recheck the operating conditions and remove the source of vibration.<br><a href="#">(Ref: 2. Safety Instructions)</a>                            |
|   |                                |                         | Remove the valve from the pipe and replace the valve or actuator.<br><a href="#">(Ref: 10.How to disassemble/assemble for parts replacement)</a> |
|   |                                | Piping around the valve | Recheck the operating conditions and remove the source of vibration.<br><a href="#">(Ref: 2. Safety Instructions)</a>                            |



**12. Cause of malfunction and remedy**

 **Caution**

 **Forcing**

**You may be electrocuted or injured.**

- ▶ If any malfunction is found, immediately stop using the product and take appropriate action.
- ▶ When removing the valve from the piping when replacing the valve or parts, completely remove the fluid from the piping before starting work.

| Failure phenomenon  | Possible cause  | Measures and measures   |
|---|---|---|
| During manual operation, the lever handle (wrench) does not turn (cannot turn). | The valve is already fully open (or fully closed).  | Rotate the lever handle (spanner) in the reverse direction.<br>(Ref: 9. Commissioning method)   |
|   | Air is supplied to the actuator.  | Close the air source valve and open the bypass valve.   |
|   | Foreign matter caught in valve  | Remove the valve from the piping, disassemble it, and remove foreign matter.<br>(Ref: 10.How to disassemble/assemble for parts replacement)     |
|   | Piping stress is applied to the valve.  | Remove the piping stress  |
|   | The torque of the valve has increased due to the effects of the fluid (temperature, components, pressure, etc.) | Reconfirm the conditions of use<br>(Ref: 2. Safety Instructions)  |
| Do not open or close by air operation.  | Air is not supplied   | Supply air.   |
|   | The solenoid valve voltage is different.  | Check the voltage with a tester to obtain the correct voltage.<br>(Ref: 4. Product specifications)  |
|   | Solenoid valve voltage is low   |   |
|   | The bypass valve is open.   | Close the bypass valve by turning the knob clockwise.   |
|   | The speed controller adjustment knob is turned all the way to the right.  | Turn the knob to the left<br>(Ref: 9. Commissioning method)   |
|   | Foreign matter caught in valve  | Remove the valve from the piping, disassemble it, and remove any foreign matter.<br>(Ref: 10.How to disassemble/assemble for parts replacement) |
|   | Valve torque is increasing due to piping stress.  | Remove the piping stress.<br>(Ref: 4. Product specifications)   |
|   | The torque of the valve increases due to the effect of the fluid (temperature, component, pressure).            | Check the operating conditions again.   |

**CAUSE OF FAILURE AND HOW TO REMEDY (continued)**

| Failure phenomenon                                 | Possible cause  | Measures and measures  |
|--|---|--|
| Do not open or close by air operation.             | Piping stress is applied to the valve.  | Remove the piping stress   |
|  | The torque of the valve has increased due to the effects of the fluid (temperature, components, pressure, etc.) | Reconfirm the conditions of use<br>(Ref: 2. Safety Instructions)   |
| Fluid leaks even when fully closed (internal leak) | High fluid pressure   | Use below the maximum allowable pressure<br>(Ref: 10.How to disassemble/assemble for parts replacement)  |
|  | The Carrier is loose.   | Remove the valve from the pipe and tighten the Carrier to adjust the surface pressure.<br>(Ref. 9. Test run method)                                |
|  | Sheet or ball is worn or scratched  | Remove the valve from the piping, replace the relevant part, or replace the valve.<br>(Ref: 10.How to disassemble/assemble for parts replacement)  |
|  | Missing parts   | Remove the valve from the piping and attach the relevant part or replace the valve.<br>(Ref: 10.How to disassemble/assemble for parts replacement) |
|  | Foreign matter caught in valve  | Remove the valve from the piping, disassemble it, and remove foreign matter.<br>(Ref: 10.How to disassemble/assemble for parts replacement)        |
|  | Piping stress is applied to the valve.  | Remove the piping stress<br>(Ref: 10.How to disassemble/assemble for parts replacement)  |

**CAUSE OF FAILURE AND HOW TO REMEDY (continued)**

| Failure phenomenon                                    | Possible cause   | Measures and measures   |
|---|--|---|
| Fluid leaks from valve<br>(external leak)             | Union nut is loose   | Retighten the Union nut<br>(Ref: 6. Piping method)  |
|   | O-ring is scratched, worn, melted, or altered                                | Stop using the product immediately, remove the valve from the piping, replace the relevant part, or replace the valve.<br>(Ref: 10.How to disassemble/assemble for parts replacement) |
|   | Scratches or wear are found on the sliding or fixing surfaces of the O-ring. | Stop using the product immediately, remove the valve from the piping, replace the relevant part, or replace the valve.<br>(Ref: 10.How to disassemble/assemble for parts replacement) |
|   | Valve is cracked or broken   | Stop using the product immediately, remove the valve from the piping, and replace the valve.<br>(Ref: 10.How to disassemble/assemble for parts replacement)                           |
| Actuator is operating but valve is not open or closed | Damaged stem, ball, or Joint   | Stop using the product immediately, remove the valve from the piping, replace the relevant part, or replace the valve.<br>(Ref: 10.How to disassemble/assemble for parts replacement) |
| Actuator is corroded                                  | The watch is exposed to water, chemical liquids, or other liquids.           | Stop using the product immediately, remove the valve from the piping, and replace the actuator.<br>(Ref: 10.How to disassemble/assemble for parts replacement)                        |
| Valve is corroded or deformed                         | The watch is exposed to water, chemical liquids, or other liquids.           | Stop using the product immediately, remove the valve from the piping, and replace the valve.<br>(Ref: 10.How to disassemble/assemble for parts replacement)                           |

**CAUSE OF FAILURE AND HOW TO REMEDY (continued)**

| Failure phenomenon   | Possible cause  | Measures and measures   |
|--|---|---|
| The Allen key does not turn (does not turn) during manual operation. | The valve is already fully open (or fully closed).  | Rotate the hex wrench in the reverse direction<br><a href="#">(Ref: 9. Commissioning method)</a>  |
|  | The power remains supplied in the opposite direction of the handle operation direction.                         | Turning the power off and then manually operating   |
|  | Foreign matter caught in valve  | Remove the valve from the piping, disassemble it, and remove foreign matter.<br><a href="#">(Ref: 10.How to disassemble/assemble for parts replacement)</a> |
|  | Piping stress is applied to the valve.  | Remove the piping stress  |
|  | The torque of the valve has increased due to the effects of the fluid (temperature, components, pressure, etc.) | Reconfirm the conditions of use<br><a href="#">(Ref: 2. Safety Instructions)</a>  |

**CAUSE OF FAILURE AND HOW TO REMEDY (continued)**

| Failure phenomenon                                 | Possible cause                         | Measures and measures  |
|--|--|--|
| Fluid leaks even when fully closed (internal leak) | High fluid pressure                    | Use below the maximum allowable pressure<br>(Ref: 10.How to disassemble/assemble for parts replacement)  |
|  | The Carrier is loose.                  | Remove the valve from the pipe and tighten the Carrier to adjust the surface pressure.<br>(Ref: 9. Test run method )                               |
|  | Sheet or ball is worn or scratched     | Remove the valve from the piping, replace the relevant part, or replace the valve.<br>(Ref: 10.How to disassemble/assemble for parts replacement)  |
|  | Missing parts                          | Remove the valve from the piping and attach the relevant part or replace the valve.<br>(Ref: 10.How to disassemble/assemble for parts replacement) |
|  | Foreign matter caught in valve         | Remove the valve from the piping, disassemble it, and remove foreign matter.<br>(Ref: 10.How to disassemble/assemble for parts replacement)        |
|  | Piping stress is applied to the valve. | Remove the piping stress   |

**CAUSE OF FAILURE AND HOW TO REMEDY (continued)**

| Failure phenomenon                                    | Possible cause   | Measures and measures   |
|---|--|---|
| Fluid leaks from valve<br>(external leak)             | Union nut is loose   | Retighten the Union nut<br>(Ref: 6. Piping method )   |
|   | O-ring is scratched, worn, melted, or altered                                | Stop using the product immediately, remove the valve from the piping, replace the relevant part, or replace the valve.<br>(Ref: 10.How to disassemble/assemble for parts replacement) |
|   | Scratches or wear are found on the sliding or fixing surfaces of the O-ring. | Stop using the product immediately, remove the valve from the piping, replace the relevant part, or replace the valve.<br>(Ref: 10.How to disassemble/assemble for parts replacement) |
|   | Valve is cracked or broken   | Stop using the product immediately, remove the valve from the piping, and replace the valve.<br>(Ref: 10.How to disassemble/assemble for parts replacement)                           |
| Actuator is operating but valve is not open or closed | Damaged stem, ball, or Joint   | Stop using the product immediately, remove the valve from the piping, replace the relevant part, or replace the valve.<br>(Ref: 10.How to disassemble/assemble for parts replacement) |
| Actuator is corroded                                  | The watch is exposed to water, chemical liquids, or other liquids.           | Stop using the product immediately, remove the valve from the piping, and replace the actuator.<br>(Ref: 10.How to disassemble/assemble for parts replacement)                        |
| Valve is corroded or deformed                         | The watch is exposed to water, chemical liquids, or other liquids.           | Stop using the product immediately, remove the valve from the piping, and replace the valve.<br>(Ref: 10.How to disassemble/assemble for parts replacement)                           |

**13. Disposal method of residual materials and waste materials**



|  |  |
|--|--|
|  <b>Warning</b> |  |
|  <b>Forcing</b> | <p><b>When burnt, toxic gas is generated.</b></p> <ul style="list-style-type: none"> <li>▶ When disposing of the product or parts, please dispose of them according to the guidelines of each local authority by a professional disposal company.</li> </ul> |

**Inquiries**

Contact the nearest dealer, our sales office, or our web website for inquiries about this product.

**[User's manual]**

3-way ball valve Type 23 Pneumatic actuated Type TA  
15~100mm



<https://www.asahi-yukizai.co.jp/en>

Please note that the content of this manual is subject to change without notice.

**April 2024**